INSTALLATION SHOULD BE CARRIED OUT BY SERVICE PERSONNEL

**Aura**™ has a swing down front guard for easy access to replace

can either be wall mounted by using the two supplied wall

screws or simply located horizontally on a desk.

MAINS WHILST CLEANING/ REPLACING PARTS.

the Synergetic<sup>®</sup> UV tube, glupac<sup>®</sup> glueboard and starter. **Aura**™

If wall mounting **Aura**™, either simply use the supplied removable

IEC mains cable to plug into the nearest power socket, or use the

INSTALLATION SHOULD BE CARRIED OUT BY SERVICE PERSONNEL ONLY,

AFTER ENSURING THAT THE UNIT IS DISCONNECTED FROM THE MAINS

discreet hard wiring option to provide power directly from a

THIS UNIT MUST BE CONNECTED TO THE MAINS SUPPLY BY AN

BEFORE HARD WIRING, ENSURE THE MAINS POWER SUPPLY IS

For hard wiring, first mark the two fixing points using the 'Hard

Wired Wall Mount Template' on the enclosed sheet, before

installing the wall plugs and fixing screws. Remove the front

metal plate of the product by unscrewing the three retaining fixing screws. (fig 1) Then remove the three short connection

wires which connect the IEC socket to the terminal block by

redundant IEC socket with the supplied blanking piece. (fig 4)

backplate with a knife, creating the hard wired mains entry port.

Next, carefully remove the 'knock out' section of the plastic

(fig 5) Offer the unit up to the two wall screws and feed the

mains wire through the newly created entry port. (fig 6) Insert

retainers. (fig 7) Finally replace the front metal plate, (fig 8)

CLEANING SHOULD BE CARRIED OUT BY SERVICE PERSONNEL

ONLY, AFTER ENSURING THAT THE UNIT IS DISCONNECTED FROM

It is recommended that cleaning is carried out regularly when

the glueboard is replaced. Once the glupac® glueboard is

removed, the unit should be thoroughly wiped down with a

damp cloth, removing any build up of dirt. Ensure the unit is

completely dry before reconnecting it to the power supply.

MOUNTING FIXING CENTRES

**Mounting Options** 

Aura

80mm

Desk

the live, neutral and earth wires into the appropriate spring

before swinging the front guard back in position. (fig 9)

pressing the three spring retainers. (fig2) & (fig 3) Cover the

ALL-POLE SWITCH TO ALLOW SAFE DISCONNECTION FROM THE

ONLY, AFTER ENSURING THAT THE UNIT IS DISCONNECTED FROM

THE MAINS SUPPLY.

SWITCHED OFF.

CLEANING

THE MAINS SUPPLY.

Wall

Professional Glueboard Insect Control

Please read these instructions carefully and store in a safe place for future reference.

As part of the Insect-O-Cutor® brand of insect control products, **Aura**<sup>™</sup> is a decorative professional flykiller which utilises a highly effective **Synergetic**® UV tube and is designed for use with a high specification glupac® glueboard.

### **CONTENTS OF PACKAGE**

- 1 x Aura<sup>™</sup> flykiller
- 1 x glupac® pheromone impregnated glueboard
- 1 x Mains cable (Type X)
- 1 x High powered Synergetic® UV tube (Fitted)
- 2 x Screws and wall plugs
- 1 x Hard wired blanking piece

WARNING - THIS APPLIANCE MUST BE EARTHED (CLASS 1)

### **INSECT CONTROL PRODUCTS**

**Aura**<sup>™</sup> utilises a high powered ultra violet tube to attract flying insects and retains the caught insects on a pheromone impregnated glueboard for inspection or hygienic disposal.

**Aura**<sup>™</sup> is not to be used by children or persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instructions. Children should be supervised to ensure they do not play with the appliance. Not suitable for applications where potentially explosive environments may exist. Skin or eye damage may result from direct exposure to ultraviolet light over prolonged periods. Always ensure the unit is disconnected from the mains supply before any form of servicing.

### POSITIONING AND GUIDANCE FOR USING AURA™

THIS UNIT IS FOR INDOOR USE ONLY, NOT SUITABLE FOR USE IN BARNS, STABLES & SIMILAR LOCATIONS. KEEP OUT OF REACH OF CHILDREN.

For most species of flying insects, **Aura**™ should ideally be fixed around two meters above the ground, preferably in the darkest place within the area to be protected. Do not position the unit close to windows, skylights or other sources of light, or where it may be obscured by furniture, doors or other obstacles. Ideally, **Aura**<sup>™</sup> should be visible from every part of the area to be protected.

However, due to its unique circular design, **Aura**<sup>™</sup> can also be mounted low to the ground, ideal for catching drain flies without revealing the caught insects to customers.

**Aura**™ should ideally be in operation for 24 hours a day, ensuring your premises are kept free of flying insects. Insects are most attracted to **Aura**™ at night when there is no competition from daylight or other light sources.

**Aura**<sup>™</sup> has a two year guarantee and if maintained as recommended in these instructions should continue to work for many years.\* Use of non-approved consumables may invalidate the guarantee. Ensure genuine glupac® glueboards are used in conjunction with this product.

\*Excludes tube, glueboard and starter. Does not cover breakdown due to misuse, incorrect operation or use in an incorrect application.

# INSECT-O-CUTOR

### GLUEBOARD REPLACEMENT

BEFORE REPLACING THE GLUEBOARD, ALWAYS ENSURE THAT THE UNIT IS DISCONNECTED FROM THE MAINS SUPPLY.

The glueboard should be replaced every month with a genuine glupac® glueboard. Use of non-approved glueboards may invalidate your guarantee. Aura™ comes supplied with a high specification yellow glueboard with printed grids for simple insect evaluation and monitoring.

To replace the glueboard...

- 1. Swing down the front guard.
- 2. Remove the used glupac® glueboard by carefully pulling it clear of the unit.
- 3. Remove the protective release paper from the new glupac® glueboard.
- 4. Maneuver the straight edges of the flat glueboard into the gap between the horizontal guard and the vertical tube chassis.
- 5. Then maneuver the glueboard together to forma a conical shape and position the glueboard under the 'front' two metal retaining clips.
- 6. Finally, tuck the two cardboard 'corners' of the glueboard under the 'back' two metal retaining clips.

Always ensure the selected genuine glupac® glueboards are compatible with your unit, available from your pest control operator or Pelsis Ltd.

TUBE REPLACEMENT SHOULD BE CARRIED OUT BY SERVICE PERSONNEL ONLY, AFTER ENSURING THAT THE UNIT IS DISCONNECTED FROM THE MAINS SUPPLY.

To ensure the efficiency of **Aura™** in catching flying insects, the UV tube should be replaced annually. After twelve months the phosphor coating that emits the correct wavelength of UV light has burnt away and the UV output is diminished substantially.

To replace the UV tube...

- 1. Swing down the front guard.
- 2. Unclip the wire tube clips.
- 3. Pull the tube away from the chassis.
- 4. Dispose of the used UV tube in conjunction with local WEEE regulations.

### STARTER REPLACEMENT

STARTER REPLACEMENT SHOULD BE CARRIED OUT BY SERVICE PERSONNEL ONLY, AFTER ENSURING THAT THE UNIT IS DISCONNECTED FROM THE MAINS SUPPLY.

The starter provides an extra spark to initially light the UV tube. The starter wears out and should be replaced at the same intervals as

To replace the starter...


- 1. Rotate the starter anti-clockwise.
- 2. Pull the starter free from the unit.

## SPECIFICATION / REPLACEMENT PARTS

Aura™ Voltage 230V ~ 50Hz 25W

**Dimensions(mm)** 270 x 270 x 135 40 Sq. Meters Coverage Weight 1.9 Kg Light Output 22W 1 x TGX22 Tubes Starter 1 x I154 Glueboards (x6) INL198 (Yellow)















# INSECT-O-CUTOR





# Hard Wired Wall Mounting Guide























rimbald Crag Close F +44 (0) 1423 863 497



www.pelsis.com